Ex. No.: 6
Date: 30/03/24

INSTALL AND CONFIGURE IPTABLES FIREWALL

AIM:

To install iptables and configure it for variety of options.

COMMON CONFIGURATIONS & OUTPUTS:

 $1. Start/stop/restart firewalls [root@localhost \sim] \# \ systemctl \ start firewalld [root@localhost \sim] \# \ systemctl \ restart firewalld [root@localhost \sim] \# \ systemctl \ stop firewalld [root@localhost \sim] \# \ systemctl \ sys$

2.Check all exitsting IPtables Firewall Rules [root@localhost ~]# iptables -L -n -v [root@localhost ~]#

3.Block specific IP Address(eg. 172.16.8.10) in IPtables Firewall [root@localhost ~]# iptables -A INPUT -s 172.16.8.10 -j DROP [root@localhost ~]#

4.Block specifig port on IPtables Firewall [root@localhost ~]# iptables -A OUTPUT -p tcp --dport xxx -j DROP [root@localhost ~]#

5.Allow specific network range on particular port on iptables [root@localhost ~]# iptables -A OUTPUT -p tcp -d 172.16.8.0/24 --dport xxx -j ACCEPT [root@localhost ~]#

6. Block Facebook on IPTables [root@localhost \sim]# host facebook.com facebook.com has address 157.240.24.35

facebook.com has IPv6 address 2a03:2880:f10c:283:face:b00c:0:25de facebook.com mail is handled by 10 smtpin.vvv.facebook.com.

[root@localhost ~]# who is 157.240.24.35 | grep CIDR CIDR: 157.240.0.0/16 [root@localhost ~]#

[root@localhost ~]# whois 157.240.24.35 [Querying whois.arin.net] [whois.arin.net]

#

ARIN WHOIS data and services are subject to the Terms of Use # available at:

https://www.arin.net/resources/registry/whois/tou/#

If you see inaccuracies in the results, please report at

https://www.arin.net/resources/registry/whois/inaccuracy_reporting/

Copyright 1997-2019, American Registry for Internet Numbers, Ltd.

NetRange: 157.240.0.0 - 157.240.255.255 CIDR: 157.240.0.0/16

NetName: THEFA-3 NetHandle: NET-157-240-0-0-1

Parent: NET157 (NET-157-0-0-0) NetType: Direct Assignment OriginAS:

Organization: Facebook, Inc. (THEFA-3) RegDate: 2015-05-14

Updated: 2015-05-14

Ref: https://rdap.arin.net/registry/ip/157.240.0.0

OrgName: Facebook, Inc. OrgId: THEFA-3

Address: 1601 Willow Rd. City: Menlo Park StateProv: CA

PostalCode: 94025

Country: US RegDate: 2004-08-11

Updated: 2012-04-17

Ref: https://rdap.arin.net/registry/entity/THEFA-3

OrgTechHandle: OPERA82-ARIN OrgTechName: Operations OrgTechPhone: +1-650-543-4800

OrgTechEmail: domain@facebook.com

OrgTechRef: https://rdap.arin.net/registry/entity/OPERA82-ARIN

OrgAbuseHandle: OPERA82-ARIN OrgAbuseName: Operations OrgAbusePhone: +1-650-543-4800

OrgAbuseEmail: domain@facebook.com

OrgAbuseRef: https://rdap.arin.net/registry/entity/OPERA82-ARIN

#

- # ARIN WHOIS data and services are subject to the Terms of Use
- # available at: https://www.arin.net/resources/registry/whois/tou/#
- # If you see inaccuracies in the results, please report at
- # https://www.arin.net/resources/registry/whois/inaccuracy reporting/#
- # Copyright 1997-2019, American Registry for Internet Numbers, Ltd. #

[root@localhost \sim]# iptables -A OUTPUT -p tcp -d 157.240.0.0/16 -j DROP Open browser and check whether http://facebook.com is accessible

To allow facebook use -D instead of -A option [root@localhost ~]# iptables -D OUTPUT -p tcp -d 157.240.0.0/16 -j DROP [root@localhost ~]#

6.Block Access to your system from specific MAC Address(say 0F:22:1E:00:02:30) [root@localhost ~]# iptables -A INPUT -m mac --mac-source 0F:22:1E:00:02:30 -j DROP [root@localhost ~]#

7. Save IPtables rules to a file

 $[root@localhost \sim] \# \ iptables-save > \sim /iptables.rules \ [root@localhost \sim] \# \ vi \ iptables.rules \ [root$

8.Restrict number of concurrent connections to a Server(Here restrict to 3 connections only) [root@localhost ~]# iptables -A INPUT -p tcp --syn --dport 22 -m connlimit --connlimit-above 3 -j REJECT

9.Disable outgoing mails through IPtables

[root@localhost ~]# iptables -A OUTPUT -p tcp --dport 25 -j REJECT [root@localhost ~]# 10.Flush IPtables Firewall chains or rules [root@localhost ~]# iptables -F [root@localhost ~]#

RESULT:

Thus the iptables are installed and configured for variety of options.